

LUBE INSTRUCTIONS

For quieter, smoother operation your door should be lubricated approximately every 3 months as shown below.

