

Care & Maintenance

RESIDENTIAL GARAGE DOORS

Congratulations on your purchase of a Raynor garage door! With proper care and maintenance, your door will perform reliably for years to come. To maintain your warranty, see the instructions below for when Raynor requires performing these maintenance items. Additional information available at www.raynor.com.

Environment	At Installation	Every 6 Months	Every 12 Months	As Needed
<p>Normal Areas not exposed to salt, salt fog, dirt or other airborne substances, or where winter road salt is not used.</p>		<p>Wash the door and windows with a mild soap (such as car wash soap or dishwashing soap) and water. Wash both interior and exterior. Rinse thoroughly. Do not use harsh or abrasive detergents.</p> <p>Lubricate track and hinges with a silicone or Teflon-based spray. Do not use WD-40® or grease. Then open and close the door to distribute the lubricant.</p>	<p>Inspect springs and hardware for signs of wear. Avoid any contact with the springs as they are under extreme tension. Call your local Raynor Dealer to schedule a service call if you</p>	<p>If surface rust appears, immediately contact your local Raynor Dealer for inspection and repair options.</p>
<p>Winter Areas where winter road salt is used.</p>		<p>Wash the door and windows. See above.</p> <p>Lubricate track and hinges. See above.</p>	<p>Inspect springs and hardware for signs of wear. See above.</p>	<p>Clean off road salt from interior and exterior surfaces. Use a mild soap (such as car wash soap or dishwashing soap) and water. Rinse thoroughly. Do not use harsh or abrasive detergents. If surface rust appears, immediately contact your local Raynor Dealer for inspection and repair options.</p>
<p>Coastal Areas with exposure to salt or salt fog.</p> <p>Harsh Areas with exposure to dirt or other airborne substances.</p>	<p>Apply a good quality car wax to the door immediately after installation, unless you are going to paint the door (see accompanying painting instructions). Follow car wax application instructions.</p>	<p>Wash the door and windows. See above.</p> <p>Wax the door. See "At Installation."</p> <p>Lubricate track and hinges. See above.</p>	<p>Inspect springs and hardware for signs of wear. See above.</p>	<p>Wash the door and windows with a mild soap (such as car wash soap or dishwashing soap) and water. Wash both interior and exterior. Rinse thoroughly. Do not use harsh detergents.</p> <p>If surface rust appears, immediately contact your local Raynor Dealer for inspection and repair</p>